



Product Handling Guidelines

The following guidelines should be used in conjunction with the CeeLite® General Warranty Statement.

General Handling

- Do not fold or crimp panels, bend around sharp objects, or roll-up tightly.
- Do not fold or crimp the pigtail lead.
- Do not alter the position of the pigtail lead after installation.....repeated handling will cause damage.
- Do not cut the panels yourself.....this voids the warranty, and may result in an electrical shock if the edges are not properly resealed.
 - Order custom sizes and shapes from the factory.
- Do not use standard panels in outdoor applications or in direct sunlight or moisture.
 - Standard panels require additional protection, such as films, laminates or inks, to prevent moisture and UV damage.
 - Custom waterproof or UV resistant panels are available from the factory.
- We recommend use of a clear protective layer such as acrylic or glass over the panel.

Storage

- Store in temperature conditions ranging from -40 °F to 176 °F (-40 °C to 80 °C).
- Store in humidity conditions no greater than 65% Relative Humidity.
- Keep panels laid out flat on shelves.

Operation

- Operate in temperatures ranging from -40 °F to 150 °F (-40 °C to 65 °C).
- Operate in humidity conditions no greater than 50% Relative Humidity.
 - Extra laminates are required for humidity conditions greater than 50% Relative Humidity.

Installation

- Install interconnecting wires in Electrical Metallic Tubing (EMT) conduit when it's necessary to install the inverter in a remote location.
 - The EMT conduit will shield the high voltage, low frequency AC signal that is output from the Inverter.
 - Refer to <http://www.steelconduit.org/installguide.htm> for a guide when working with EMT conduit.