





CeeLite INV-US050 Inverter Operation Instruction

Instruction:

1. Make sure the slide switch is on the OFF position.
2. Connect the DC power cord to the power source. The DC power cord could be a cigarette plug or an adapter or hardwires in one end, and plug into the DC jack; the power rating should be 12VDC.
3. Ensure that the **CeeLite** Panel is connected to the **CeeLite** Inverter.
4. If the slide switch is set to the ON position, the **CeeLite** Panel will be illuminated continuously. If the slide switch is set to the FLASH position, the **CeeLite** Panel will be illuminated for 2 seconds and dimmed for 1 second alternatively.
5. Use DIMMER Dialing Knob to adjust **CeeLite** Panel brightness from Dark to Bright.
6. During normal operation, if no load is detected (e.g. the panel is not connected), the **CeeLite** Inverter will automatically shut down, and once the load is reconnected operation will resume automatically.



Cigarette Plug



Adapter



Hardwires

Specifications are subject to change without prior notice.



WARNING

NOTE: These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- The 3rd pin of the power cord should be grounded to prevent shock and radio interference.

Notice:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Specifications are subject to change without prior notice.